Instruction



1.Take the steel frame out of the box Straighten,then insert steel tube one side after one side.



2.Lock the button.



Remark: before insert, please check the connector, open the lock. And press the two small buttons flatly so that the steel tube can be inserted.



3.Fold frame from both sides to the middle.



5.Push the frame to each corner.



6.Slide the tube lock half way up,then insert the steel tube into the lock and push them up to the top.



Slide the tube lock in the direction of the arrow.



Fold it down and lock the straps.